Yealink W70B

Yealink

Yealink
End User Guide

Contents

End User Guide for Yealink W70B

Introduction

This guide will help you get up and running with your new desk phone. For an explanation of the listed features please reference the AirePBX Feature Guide at https://airespring.com/resources/resources-others/?d=guides.

Accessing the CommPortal

To configure phone, log in at https://commportal.airespring.com/

Once you login, select Devices and add the Yealink W70B

Once you access to the phone page, the following screen will display:

1

Features

In this section you may enable or disable Call Log.

Preferences

Advisory Tones

In this section you'd enable or disable the call connection beep tone when receiving the outgoing call.

Call Log

In this section you'd enables or disables the IP phone to save local call log.

Call display

In this section you'd enable or disable the IP phone to display the called contact information and method when receiving an incoming call.

Lines 1 – 10

In this section you will be able to configure:

Number, Name, Description Line settings for the front screen display or either Directory Number, Extension Number, or a desired Custom Descriptions. The * code setting for accessing Voicemail is displayed.